

PICTURE ONE ►

Acculock adjuster with bolts and washers used to fasten the adjuster through the cradle bottom into the playfield



PICTURE TWO ▼

AccuLock adjuster bolted in place. Make sure the playfield is centered in the cradle and then finger tighten all three bolts to hold the adjuster to the cradle and playfield. Notice, there is a gap in the center of the adjuster between the bottom of the cradle and the adjuster.



PICTURE THREE ▼

AccuLock adjuster installed. Tighten the two outside bolts until they are snug and then tighten the center bolt until the gap disappears. DO NOT OVER TIGHTEN BOLTS.

